



ERASING OLD CODES

Locate the ANTENNA wire on the back or side of the motor (if your ANTENNA is **PURPLE** look at the 3500 series diagram below, if the ANTENNA is any other color use the 1200 series diagram). Next find the SMART button. The SMART button is used to add subtract transmitters and keypads.

CODING INSTRUCTIONS

TO CLEAR OUT OLD CODES

Press and **HOLD** the **SMART** button for **20 seconds** release the SMART button and try any existing transmitter to make sure the old code is gone.

TO ADD A TRANSMITTER

Press and **RELEASE** the **SMART** button and immediately press the appropriate button on the transmitter **4 TIMES SLOWLY**

Repeat above step with any remaining transmitters

